



Initial Rim Backboard Assembly

Slide 4 Bolts (A) through Rim holes (B) and Backboard holes (C). Slip 1" Washers (D) over Bolts and tighten against back of backboard with Hex Nuts (E) Using wrenches or pliers. Push Clear Spacers (F) over Bolts against Hex Nuts.

Unit Assembly

Fill Base with water and install Plug. Align Bolts on Rim Backboard Assembly with Post Holes (G) and slide through, securing with Hand Knobs (H).



For assistance call
1-800-798-9646

Parts List

WHITE HAND KNOBS.....	4
BOLTS (1/4 X 3 1/2).....	4
CLEAR SPACERS.....	4
FENDER WASHERS.....	4
NUTS	4
BASE PLUG.....	1
INFLATION NEEDLE.....	1