



low range  
PHOSPHATE  
TEST KIT

Code 3466

# TEST PROCEDURE

1

Fill the test tube (0106) to the 10 mL line with sample water.



2

Add one \*Phosphate LR Testab (6836A) and cap tube.



3

Invert tube repeatedly. Mix until tablet disintegrates.



4

After tablet disintegrates, wait 6 minutes. Invert once to mix, then remove cap.



5

Place tube bottom on the color chart inside the dotted lines. Look down through the tube to determine the results as ppb Phosphate.



Store the kit at room temperature.

 **LaMotte**

PO Box 329 • Chestertown, MD 21620  
800-344-3100  
410-778-3100 (Outside USA)  
[www.lamotte.com](http://www.lamotte.com)

\*Potential health hazard. Read SDS at: [lamotte.com](http://lamotte.com).

6.16 • 63466